

WAYFINDING SIGNAGE INSTALLATION GUIDE



Table of Contents

1. Have the Right Tools	1
2. How to apply the tape and epoxy glue on signs	3
3. Follow Special Rules for Unit Numeration	4
4. Installation of Signs in Corridors	5
5. Installation of Signs on Stairs	6
6. Installation of Signs in Elevators	7
7. Installation of Signs in Technical Rooms	8
8. Installation of Other Signs	11
9. Installation of Signs in Clubhouse	12
10. Frosted vinyl sign	15
11. Installation of Signs in Pool Area	17
12. Installation of Outdoor Signs	19
Building Address	19
Site Directional	22
Monument Sign	23
Other Sign	24
13. High Voltage and Low Voltage Sticker	26
14. Final Recommendations	27



1. Have the Right Tools

Before you begin mounting any ADA sign, it's important to have the right tools on hand. Grab a tape measure, pencil, spatula, alcohol, soft rags and level to help identify and mark the correct placement for each sign





To ensure permanent adherence of the signs to the surface and to avoid damage from the glue to the sign or the transparency of the stickers to the front of the sign, we require the use of the following products:



3M VHB REF 5950Double side acrylic foam tape



Liquid Nails Fuze ItAll Surface



Gel Control
(For metalic address on monument sign only)



2. How to apply tape and epoxy glue on signs


Place tape only on the longer side of the sign and glue in the center. Here are some examples:













Building Address



3. Follow ADA Code for Unit Numeration


Unit numbers must be installed next to the latch side at a height of 48 inches from the floor.



Note: ADA signs must be seen and understood by anyone entering the property, soyou should avoid installing any signs where they are hidden by open doors or furniture




4. Installation of Signs in Corridors



From the building outdoor covered edge of at **entrance only**



5. Installation of Signs on Stairs



From the building outdoor covered edge of at **entrance only**

Sign under stairs: APO/No Storage



6. Installation of Signs in Elevators





7. Installation of Signs in Technical Rooms






7. Installation of Signs in Technical Rooms



RVA marketing

7. Installation of Signs in Technical Rooms








8. Installation of other signs







9. Installation of Signs in Clubhouse



RVA marketing

9. Installation of Signs in Clubhouse





RVA marketing

9. Installation of Signs in Clubhouse







10. Frosted vinyl signs



59"



10. Frosted vinyl signs



Note: The frosted vinyl stripes should be located with respect to the door handle. They must be installed below the handle, in the middle

RVA marketing

11. Installation of Signs in Pool Area







Note: Use 3M VHB 5950 only on handrails - do not use epoxy glue.



11. Installation of Signs in Pool Area







12. Installation of Outdoor Signs Building Address




Note:

Left aligned with window centered between scoreline and building top.

Note:

Left aligned with window centered between scoreline and building top.





12. Installation of Outdoor Signs Building Address















12. Installation of Outdoor Signs Building Address





12. Installation of Outdoor Signs Site Directional







12. Installation of Outdoor Signs Monument Sign



Current design is garante, RESIA will provide the approved design are specifications for the production and installation of the monumental sign.



* NOTE

Letters and numbers in 3/8" aluminum with baked-on paint and epoxy glued. For details of materials, see construction plan.





12. Installation of Outdoor Signs Other Sign





13. High Voltage and Low Voltage Sticker

Unit numbers must be installed next to the latch side at a height of 48 inches from the floor.





13. High Voltage and Low Voltage Sticker

Low voltage sticker should be installed in rooms like: fire command center, elevator control room, IDF room, MDF room, BDA fire alarm





14. Final Recommendations

- Refer to the wayfinding plans for more sign specifications.
- If the surface where the sign will be installed is very cold, we recommend using an industrial dryer on the surface before installing.
- Where a tactile sign is provided at a door, the sign shall be located alongside the door at the latch side. Where a tactile sign is provided at double doors with one active leaf, the sign shall be located on the inactive leaf. Where a tactile sign is provided at double doors with two active leafs, the sign shall be located to the right of the right hand door. Where there is no wall space at the latch side of a single door or at the right side of double doors, signs shall be located on the nearest adjacent wall. Exception: Signs with tactile characters shall be permitted on the push side of doors with closers and without hold-open devices. (Standard 703.4.2)

Please visit https://rva-marketing.com/en/safety/ for more information, plans, ADA codes, project info and more.